


Kids Easel

ASSEMBLY INSTRUCTIONS

mocka

Thank you for your purchase.
Please follow the instructions below for correct assembly.




Recommended for children 18+ months

Kids Easel

ASSEMBLY INSTRUCTIONS



mocka

1



To assemble, simply attach the tray and fully extend the legs to lock the tray into place.

2



You're done, enjoy!